


USB Host Parameters

USB Device Type

Select the desired USB device type.




When changing USB Device Types, the scanner automatically restarts. The scanner issues the standard startup beep sequences.



***HID Keyboard Emulation**



IBM Table Top USB



IBM Hand-Held USB



USB OPOS Handheld